


P606 | Gas Cylinder Lockout User Manual

Material Content:


a. Gas Cylinder Lockout

b. Self-adhesive Label



SuperLock®
LÍDER EN CERRAJERÍA DE ALTA SEGURIDAD

Application:



1. Open both hinged covers so that the gas bottle lockout device is fully open from below.

2. Place the open end over the gas cylinder valve.



3. Close the hinged cover so that it tightly encloses the valve stem of the gas cylinder, the hinged cover ends can be inserted in the mounting provided for this purpose, and a hole is thus available for attaching a padlock.



4. Insert a padlock through the provided opening for it.

5. Lock the lock. Pull on the gas cylinder lockout device to ensure that the gas cylinder valve cannot be exposed and is safely locked.

WARNING:



Product should only be used by personnel properly trained in lockout procedures. Product should only be used on the appropriate application (s). Follow product instructions for proper application of each product. Properly trained personnel should check to ensure that product is secure and equipment will not operate. Failure to follow product instructions and warnings may result in serious bodily injury or death.

You will find additional notes and corresponding application videos to every lockout device following the link:
<http://www.abus.com/eng/Service/Videos/Industrial-safety>